


# Shed Link V3 Easy Setup Guide



V20250515

Latest Version of this document available at:

https://github.com/UBWH/ubwh.github.io/blob/master/assets/UserGuides

Easy Setup Guide: Shed Link V3

# **Table of Contents**

1. Before You Start	3
2. Step By Step - Configuration	4
2. Step By Step - Shed Setup	


Easy Setup Guide: Shed Link V3

## 1. Before You Start

D	
Decide device to configure the	You will need this as your <b>Configuration Device</b> :
Shed Link unit	Computer/Tablet/Phone with WiFi
Locate the unit in the Home	Place the <i>EAP110-Outdoor</i> (EAP) unit in the home in a room where it:
	is on the side of the house closest to the shed, and
	will be able to connect to the existing Home WiFi signal.
Power the unit	Connect the power adapter with a LAN cable (not included) between the POE port of the included Passive PoE adapter (24 V), and the EAP. The EAP will power up.
Factory Default	The Shed Link unit must be in Factory Default state.
	If you are unsure:
	Wait until the LED on the side stabilises.
	Using a straightened paper-clip (or similar), press and
	hold the Reset button near the LAN cable connector, until
	the LED flashes and comes back on solid GREEN.
	Approx 10 sec.
	RESET
Install ONE internal antenna.	Install one of the internal (rigid) antennas on either antenna connector.
	<b>D</b> (p-link
Know the WiFi credentials of your HOME WiFi	Write here the credentials of your existing (Home) WiFi:
	SSD (WiFi Name):
	Password (PSK):


Easy Setup Guide: Shed Link V3 Page 3 of 12

#### 2. Step By Step - Configuration




Easy Setup Guide: Shed Link V3

	Choose new login details for the EAP and record here:
	EAP Username:
	EAP Password:
	Set up a new account
	New Username:
	New Password:
	Confirm Password:
	Allow Data Collection:   Enable (i)
	Next
	Click Next
Select Repeater mode	Select Repeater Mode
	AP Mode
	In this mode, the AP connects to a router via an Ethernet cable and transforms the wired network into a wireless one.
	Repeater Mode
	In this mode, the AP connects to the existing network wirelessly and expands its wireless coverage.
	Next
	Click Next




Configure the Shed WiFi Network In this step, you will configure the WiFi network for inside the Shed.


It is recommended to simply use the **SAME** SSID (WiFi Network name) and Password as used in the Home. But you are free to use different SSID/Password if you prefer.



Click Next



#### Congrats!




Your Shed Link is now configured.


Disconnect all cables and take the EAP to the shed.

If you used a Mobile Phone for configuration, you can turn Mobile Data back on now.

## 2. Step By Step - Shed Setup



Easy Setup Guide: Shed Link V3 Page 10 of 12



Apply power	Apply power to the unit.
Test	Using a phone or WiFi computer in the shed: Connect to the WiFi network and you should be able to browse the Internet.
	Optional: A PC/TV/etc can be connected by a LAN cable to the LAN socket on the 24V PoE adapter powering the EAP.
EAP login Access	If you want to login to the EAP at <a href="http://tplinkeap.net">http://tplinkeap.net</a> in the future, you MUST do it from within the Shed.
	You can not do it from the Home LAN or WiFi within the Home.